


Yellow Tube - Urine Specimen - CGT, CG Collection Instructions

Collection Procedure



Yellow Tube

CGT, CG




Step 1

Have patient collect specimen in a sterile, plastic, preservative-free specimen collection cup.
NOTE: Patient should not urinate for at least 1 hour prior to collection of specimen. Patient should collect only the first 20 to 60 mL of voided urine.




Step 2

Have patient securely place the cap on the urine collection cup.




Step 3

Label collection cup with patient identification, date, and time collected.
NOTE: Wear clean gloves when handling Urine Transport Kit components and urine specimens. If gloves come into contact with the specimen, immediately change gloves.




Step 4

Uncap the Urine Sample Buffer Tube and the urine sample cup. Immediately after collection, use the graduated transfer pipette to gently and thoroughly mix the urine specimen. Then, following guidelines on the pipette, use the pipette to aspirate approximately **2 mL** of the urine specimen from the collection cup.



Step 5

Transfer **2 mL** of the urine specimen into the Urine Sample Buffer Tube. Use the graduations on the transfer pipette as a guide. **DO NOT** overfill or under fill the tube.
NOTE: The transfer pipette is intended for use with a single specimen only.



Step 6

Tighten the cap securely on the Urine Sample Buffer Tube. Invert the tube 3 to 4 times to ensure that the specimen and reagent are well mixed.



Step 7

Do Not Cover this barcode.

Do NOT apply labels or markings across the cap or over the barcode at the top of the product label. The label must wrap completely around the tube, overlap with itself, and be wrapped tightly, smoothly, and securely onto the tube with no loose edges, tails, or wings exposed.

Label Yellow tube with patient information, date, and time collected. Be careful not to obscure the barcodes on the tube.

